

Settings Utility V0.4 - How To

To save the current settings of the WR-2 web relay device to a file enter the IP address of the device in the field to the right of the download buttons. Enter the setup page password in the password field to the left of the download buttons. Click the Download Settings button to save the settings to a file. Click the Download Events buttons to save the events to a file. Note: A popup window will appear asking for the filename. Name the settings file and events file different names.

Events File contains all the Relay settings
Settings file contains all network IP settings

To upload settings to the WR-2 web relay device, go to the File menu and select Open. Select the settings file first. Once opened, hit the Upload Settings button. To upload events to the device, first open the event file following the previous instructions. Once the file is loaded, press Upload Events. Note: the IP address and password used to upload settings to the device is different than those used to download settings. The IP address and password fields for use in uploading settings are found to the right of the Upload buttons.

Default username=admin

Default password=admin

BellTimers.com 1-888-327-8463 North American Toll Free
Other areas 1-905-527-8463
info@belltimers.com